



APR CONTROL INSTALLATION DIAGRAM SINGLE EVAPORATOR HEAT-PUMP SYSTEM

Heating Mode



Cooling Mode



APR-3hpp dir 8-9-03

Tel. 800-727-6447
Fax 781-933-3306

RAWAL DEVICES, INC.

www.rawal.com
sales@rawal.com